

POWER ANALYZER
CVM-MINI-Ethernet



This manual is a quick guide to the use and operation of the **CVM-MINI-ITF** & **CMV-MINI-MC** with Ethernet connection. For more information, the whole manual may be downloaded from CIRCUTOR's web page: www.circutor.es

! Before any maintenance, modification to the connections, repair, etc., the equipment must be disconnected from the supply. If any operation or protection fault is suspected the equipment must remain out of service ensuring against any accidental reconnection. The equipment is designed to be changed quickly in the event of any breakdown.

The **CVM-MINI** is an instrument which measures, calculates and displays the main electrical parameters for three-phase industrial systems (balanced or unbalanced). Measurements are in true effective value, via three AC voltage inputs and three AC current inputs. (via $I_n / 5 A$ or $1 A$ the ITF version and $I_n 0,25A$ MC version). The parameters measured and calculated are shown in the variables table, paragraph 7.

1.- INSTALLATION

The equipment is mounted on DIN rail. Also the device has to be provided of a magnetic-thermal switch to be disconnected. The fuses has to be type gl (IEC 269) or type M between 0,5 to 2 A.

2.- ETHERNET NETWORK SETUP

The configuration software, IPSETUP.EXE, is available from the **CIRCUTOR** Web site. It must be executed under Windows operative system. Once executed it will appear the following screen



In the field "**MAC**" it must be typed the physical address of the unit using scripts as separator, this data is showed on to the lateral label of the equipment and the format is 14:A6:2C:XX:XX:XX.


In to the field "**Dirección**", type the assigned IP address to the equipment into the local area network

Into the field "**Netmask**" type the mask for the network.

In case of routing the equipment in a different network, setup the field "**Gateway**" with the IP address of the device that allows the route. For example, if the equipment must be accessible from Internet, will be necessary setup the IP address for the ADSL router that allows the Internet connection. Also the router will need convenient programming to allow Internet enroute and enable the traffic from/to the **CVM-MINI-Ethernet**. If it is not the case leave the field "Gateway" in blank.

3.- DHCP IP assignment

To assign the DHCP name, choose this option using the arrow on the upper right, and select "On". Once the configuration fields have been enabled, enter the "**MAC**" address that can be seen on the permanent side label attached to the device, the format of which is **14:A6:2C:XX:XX:XX**. In the "**Dirección**" field, enter an unused, temporary IP address, which is within the working range of your computer. In the "**Host Name**" field, enter the **DHCP** name to be assigned to the equipment. Optionally, the user can configure the parameters of the "**ClientID**" field. The default "**VendorID**" of the device is **CIRCUTOR**.



Once the parameters have been configured click on "**Configurar**"


If the equipment is detected into the Ethernet network, it will appear the following screen.



By clicking "**Aceptar**" the internal setup WEB page of the equipment will be displayed.



If the equipment is not detected on the local network it will appear the following screen.



Review the settings assigned to the computer, check the connection to the router and the Ethernet Connector LEDs are lit and / or blink. The LED on the left side of the connector is the link status and the LED on the right side indicates activity receive / transmit TX / RX. Both can be lit in green or amber color. If everything appears correct, consult with your admin for the local area network.

4.- SETTING (SETUP menu)

(Press SETUP key for 5 seconds)

- The key validates the information and moves on to the next menu.
- The key allows the different options in a menu to be selected or increases a digit where a variable is being entered.
- The key is used to move the cursor among the digits.

The different options are sequentially described below.

4.1.- Voltage transformer primary

On screen the words "**SET PR1U**" appear followed by 6 digits. These allow the voltage transformer primary to be set (from 1 to 100,000).

4.2.- Voltage transformer secondary

On screen the words "**SET SECU**" appear followed by 3 digits. These allow the voltage transformer secondary to be set (from 1 to 999).

4.3.- Current transformer primary

The display show "**SET PR1R**" followed by 5 digits. These allow the current transformer primary to be set (from 1 to 10,000).

In the case of using a transforming system type MC1, introduces the primary of the transformer corresponding to the relation of the selected physical wiring. In case of using type MC3, introduces the value of the primary that appears in the label of the transformer.

4.4.- Current transformer secondary.

The display show "**SET SECU'**". In the ITF versions, selection is allowed between 1 and 5 A. In the MC version, this parameter is not available in the equipment configuration menu.

4.5.- Measurement in 2 or 4 quadrants (power consumption and/or generation).

On screen the words "**SET QUAD**" appear (2 =Power consumption / 4 =consumption and generation)

4.6.- Setting the Power demand meter:

a) Electrical parameter to control: ("**SET PD CODE**"):

None		00
Three-phase active power	<i>kW III</i>	16
Three-phase apparent power	<i>kVA III</i>	34
Three-phase current	<i>A III</i>	36
Current per phase	<i>A1-A2-A3</i>	A-PH

Integrated parameter value according to the set period.

b) Integration period (1...60 minutes): ("**PD PER 15**")

c) Clear maximum value recordings of Pd: ("**CLR PD NO**") "**NO**" or "**YES**".

4.7.- Setting display or omitting screens

This option allows the page display format to be displayed ("**DEF PAGE YES / NO**"):

- I. **YES** | Standard: se all electrical parameters are displayed.
- II. **NO** | Custom: by using the "YES" or "no" option the pages to be displayed when the equipment is on are selected.

4.8.- Setting the start screen

This option allows select the screen and selection mode of display screens ("**SET INIT PAGE**"):

- I. **Fixed page**: selects which page from the possible pages will appear first when applying voltage (or on RESETTING) to the **CVM-MINI-Ethernet**.
- II. **Rotating pages**: selecting rotating pages (when all of the electrical parameters flash), automatically rotates, every 5 seconds it moves on to the following screen.

4.9.- Setting the “backlight” disconnection time

(“DISP OFF”): Setting the time in seconds, after which the light on the **CVM-MINI -Ethernet** display switches off (low consumption) after a key is pressed. If 00 is set, the backlight is permanently on.

4.10.- Returning the energy counters to zero

“CLR ENER” “YES” or “NO” (Clear energy counters) appears on the display.

4.11.- Setting THD or d

Two types of Harmonic distortion can be set (“SET HAR D”):

- d %: value harmonic distortion with respect to the fundamental.
- Thd %: value harmonic distortion with reference to the effective value (RMS).

4.12.- Additional screen with transistor alarm outputs

(“OUT 1 CODE” / “OUT 2 CODE”) With these outputs the **CVM-MINI-Ethernet** transistor output is set for:

- 1.Impulse every *n* kW.h or kvar.h (Energy): The value in kW.h is set corresponding to one impulse (100 msec long.): kW.h / 1 impulse or kvar.h / 1

impulse. Maximum 5 imp/sec. (see variable codes).

II.**ALARM conditions:** each output is set per transistor the variable to be controlled, the maximum value, minimum value and the (delay) (see variable codes).

Note: The list of variable appears in the table below.

5.- CVM-MINI-Ethernet Blocking SET UP

This menu allows to block the setup parameter to avoid changes. To access to this menu:

Press the  key and pressing the  key for five seconds until Set-Up is entered.

Briefly appear on the display “SET UP INIT” and after “SET UP” with the option::

UNLO Allows configuration of the device parameters using the keypad.

LOC Bloquea la configuración de los parámetros del equipo mediante el teclado.

If the Loc, option is selected, it is only possible to see the setting on entering SETUP and the changes are not allowed.

To select this options press  **max**

NOTE: to disable the unlock mode enter the password 1234 when asked.

If a previously set option is to be changed, then it is necessary to enter a password. **PASSWORD CVM-MINI -Ethernet 1234.**

6.- CVM-MINI-Ethernet COMMUNICATIONS

One or more analysers **CVM-MINI-Ethernet** can be connected to a “router” or “switch” Ethernet and access their information through a PC connected to the same Ethernet local area network. This system allows centralizing data on a single registration point (Studio @ Power System).

To change the communication settings see section 2.

The network analyzer type **CVM-MINI-ETHERNET** communicates using **MODBUS TCP ©** (Pulling Question / Answer).

7. - LIST OF VARIABLES AND ALARMS CODES FOR THE CVM-MINI - Ethernet

➤ If no variable is required enter No. par.= 00.

Parameter	Symbol	L1 Code	L2 Code	L3 Code
Voltage (phase-neutral)	V	01	06	11
Current	A	02	07	12
Active power	kW	03	08	13
Reactive power -(Ind/Cap)	kvar	04	09	14
Apparent power	kVA	38	39	40
Power factor	PF	05	10	15
% THD V	THD V	25	26	27
% THD A	THD A	28	29	30


There are also some variables that refer to the three-phases at the same time. If one of these variables has been selected, the alarm will go off when any of the three-phases meet the preset conditions.

Parameter	Symbol	Code	Parameter	Symbol	Code
Voltages (phase-neutral)	V1 or V2 or V3	90	Power factors	PF1 or PF2 or PF3	94
Currents	I1 or I2 or I3	91	Voltages (phase-phase)	V12 or V23 or V31	95
Active powers	kW1 or kW2 or kW3	92	% THD V	THDV1 or V2 or V3	96
Reactive powers	kvar1 or kvar2 or kvar3	93	% THD I	THDI1 or I2 or I3	97
Apparent powers	kVA1 or kVA2 or kVA3	98			

Parameter	Symbol	Code	Parameter	Symbol	Code
Three-phase active power	kW III	16	Neutral current	I_n	37
3 pha. inductive power	kvarL III	17	Max demand (L1)	Md (Pd)	35*
3 pha. capacitive power	kvarC III	18	Max demand (L2)	Md (Pd)	42*
cos φ three-phase	cos φ	19	Max demand (L3)	Md (Pd)	43*
3 pha. power factor	PF III	20	Active energy	kW.h III	31
Frequency (L1)	Hz	21	Inductive reactive energy	Kvar-h L III	32
V phase phase L1- L2	V 12	22	Capacitive reactive energy	Kvar-h C III	33
V phase phase L2 - L3	V 23	23	Apparent energy	KVA-h III	44
V phase phase L3 - L1	V 31	24	Active energy generated	Kw-h III -	45
Apparent power	kVA III	34	Inductive energy generated	Kvar-h L III -	46
Maximum demand	Md (Pd)	35	Capacitive energy generated	Kvar-h C III -	47
Three-phase current	A III	36	Apparent energy generated	KVA-h III -	48
Temperature	°C	41			

*Variables only valid if the Maximum Demand for current has been set per phase.


8. - FOUR QUADRANTS OF THE CVM-MINI -Ethernet



9.- TECHNICAL FEATURES

<p>Power supply circuit:</p> <ul style="list-style-type: none"> - Single-phase: - Voltage tolerance: - Frequency: - Maximum consumption: - Operating temperature: - Humidity (without condensation): 	<p><i>AC. version</i> 230 V AC. -15 % / +10 % 50 - 60 Hz 3,0 VA -10°C+ 50°C 5% 95%</p> <p><i>Plus version: AC. & DC.</i> 85.265 V AC/ 95.300V DC. 50 - 60 Hz (AC. mode) 3,0 VA -10°C+ 50 ° C 5% 95%</p>	<p>Measurement circuit:</p> <ul style="list-style-type: none"> - Rated voltage: phase-neutral / between phases - Frequency: - Rated current: - Permanent overload: - Power consumption voltage circuit: - Power consumption current circuit: ITF / Shunt 	<p>300 V AC. / 520 V AC. 45 ~ 65 Hz ITF I_n / 5A-1A 1.2 I_n 0.7 VA 0.18 VA</p>
<p>Mechanical features:</p> <ul style="list-style-type: none"> - Casing material: - Protection: - Assembled equipment (front): - Non assembled equipment (sides and rear cover): - Dimensions (mm): - Weight: - Voltage measure and supply wires: - Secondary current transformers wires: - Maximum altitude: 	<p>Self extinguishing V0 plastic</p> <p>IP 51 IP 31</p> <p>85 x 52 x 70 mm (3 step) 0.210 kg Minimum section 1 mm² Minimum section 2,5 mm² 2.000 m.</p>	<p>Output transistors features</p> <ul style="list-style-type: none"> - Type: Opto-isolated transistor (open collector). - Maximum operating voltage: - Maximum operating current: - Maximum frequency: - Impulse length: 	<p>NPN 24 V DC. 50 mA 5 impulses / second 100 ms</p>
<p>Accuracy class:</p> <ul style="list-style-type: none"> - Voltage: - Current : - Power / Energy: <p>Measurement loggers: Current / Voltage Power factor: Scale range measurement margin: ITF / Shunt Temperature sensor: Accuracy / Operating window - T^a measurement: Without / with forced ventilation</p>	<p>0.5 % ± 1 digit 0.5 % ± 1 digit 0.5 % ± 1 digit</p> <p>External transformers / direct voltage 0.5 to 1 0.2 % 120 % / 2 % 120 % ± 2°C / -10°C +50°C + 14.0 °C / + 3.5 °C</p>	<p>Ethernet connexion Internal WEB for Ethernet setup. IP address assignment by DHCP or name Password access protection RJ45 connection</p> <p>Left LED Connector Indicator. Link Status: Right LED Connector Indicator 10M/100M:</p> <p>Standard IEEE802-3u</p>	<p>Green FULLDUPLEX Ambar HALFDUPLEX</p> <p>Green 100 Mb/s Ambar 10 Mb/s</p>
		<p>Safety: Category III - 300 V AC. / 520 AC. EN-61010 Class II double insulation against electric shock</p> <p>Standards: IEC 664, VDE 0110, UL 94, IEC 801, IEC 348, IEC 571-1, EN 61000-6-3, EN 61000-6-1, EN 61010-1, EN 61000-4-11, EN 61000-4-2, EN 61000-4-3, EN 61000-4-4, EN 61000-4-5, EN 55011</p>	

10.- CONNECTIONS



11.- TECHNICAL SERVICE

In the event of any equipment failure or any operational queries please contact the technical service of **CIRCUTOR**.

CIRCUTOR, S.A. - Technical Assistance Service (S.A.T)
 Vial Sant Jordi, s/n
 08232 - Viladecavalls (Barcelona)
 Tel.: (+34)93 745 29 19
 Fax - 93 745 29 14
 E-mail : sat@circutor.com